

ONIKUMA


Panduan Pengguna

T309

*Harap baca manual dengan teliti dan simpan untuk penggunaan di masa mendatang.

Indonesia

Petunjuk untuk setiap bagian dari produk



1. Telinga kiri
2. Telinga kanan
3. lubang mikrofon
4. Tombol sentuh (MFB).
5. Antarmuka pengisi daya tipe-C
6. Wadah pengisian daya
7. Lampu indikator wadah pengisi daya

Penggunaan

1. Cara memakai yang benar
L headset untuk telinga kiri, dan R untuk telinga kanan. Untuk pengalaman audio yang lebih nyaman, silakan coba masing-masing ukuran penutup telinga. Ketika headset terpasang dengan benar akan terasa nyaman dan aman di telinga anda.
2. Penggunaan di luar ruangan
Tubuh manusia mengandung banyak air, yang dapat menimbulkan interferensi kuat terhadap sinyal Bluetooth. Umumnya, earphone diatur untuk menerima sinyal Bluetooth dari ponsel. Disarankan untuk meletakkan ponsel di saku di dekat telinga, yang secara efektif dapat mencegah dan memblokir sinyal dan meningkatkan kemampuan anti gangguan saat digunakan.



Instruksi

1. Pengisian daya produk
a. Gunakan pengisi daya DCSV-1A Tipe-c untuk mengisi daya wadah pengisi daya, lampu oranye selalu menyala saat mengisi daya, dan lampu hijau selalu menyala saat daya terisi penuh.
b. Untuk mengisi daya headset, masukkan headset ke dalam wadah pengisi daya dan tutup, headset akan mengisi daya secara otomatis.
2. Menyambungkan ke peralatan
a. Buka penutup wadah pengisi daya, dan kedua earphone akan menyala dan terpasang secara otomatis.
b. Segarkan perangkat Bluetooth ponsel, temukan T309, pilih untuk menyambungkan
3. Koneksi earphone satu sisi
a. Metode pemasangan earphone satu sisi sama halnya dengan langkah poin 2 diatas. (gunakan earphone sisi kiri, keluarkan earphone sisi kiri dari wadah dan tunggu sekitar 10 detik untuk mencari koneksi)
4. Mengatur ulang earphone (Atur ulang earphone jika earphone tidak tersambung atau Bluetooth tidak dapat menemukan perangkat)
a. Ketika Bluetooth tidak terhubung, tekan cepat tombol MFB 4 kali pada earphone kiri/kanan, dan akan ada "bip bip" setelah menghapus catatan koneksi.

Kontrol fungsi

Hidupkan daya	Sentuh dan tahan MFB selama 3 detik
Matikan daya	Masukkan earphone ke wadah pengisi daya
Putar/jeda	Sentuh MFB
Trek sebelumnya	Sentuh 2 kali MFB sebelah kiri
Trek berikutnya	Sentuh 2 kali MFB sebelah kanan
Jawab/tutup panggilan	Sentuh MFB
Tolak panggilan	Sentuh dan tahan MFB 2 detik
Aktifkan asisten suara	Sentuh MBF earphone sebelah kiri 3 kali
Mode game	Sentuh MBF earphone sebelah kanan 3 kali

Parameter produk

Versi Bluetooth	5.3
Format audio	SBC、AAC
Daya tahan baterai	≥4H
Pengisian daya (wadah)	<2H
Pengisian daya earphone	<2H
Jangkauan	≥8m
Ukuran produk	52,2X22X48mm

Pertanyaan yang Sering Diajukan

1. Ponsel tidak dapat mencari earphone
a. Untuk memastikan apakah headset telah dihidupkan, harap hidupkan ulang headset dan telepon, dan ulangi langkah pencarian bluetooth earphone.
b. Harap pastikan bahwa headset tidak terhubung ke perangkat Bluetooth lain.
2. Earphone kiri dan kanan tidak bisa dipasangkan
a. Masukkan earphone ke dalam wadah pengisi daya dan keluarkan lagi.
b. Sambungkan kembali setelah menyetal ulang earphone.
3. Ada derau sambungan terputus antara headset dan ponsel
a. Ada penghalang atau gangguan sinyal listrik lainnya antara perangkat dan earphone, harap pastikan tidak ada penghalang antara earphone dan perangkat, dan cobalah untuk tidak menggunakannya di lingkungan yang kompleks.
b. Rentang jangkauan efektif earphone dan perangkat/ponsel umumnya dapat mencapai 8 meter. Secara umum, efek terbaik dapat dicapai tanpa penghalang, dan kebisingan, koneksi akan terputus jika jarak jangkauan terlampaui.
4. Headset tidak mengisi daya.
a. Harap pastikan sambungan antara earphone dan wadah pengisi daya terpasang dengan baik.
b. Jika ada kotoran atau noda air pada titik kontak pengisian daya, harap bersihkan.

ONIKUMA


MANUAL

T309

*Please read the manual carefully and keep it for future use.

ENGLISH

Descriptions



1. Left earpiece
2. Right earpiece
3. Microphone hole
4. Multifunction button (MFB)
5. Type-C charging port
6. Charging case
7. Charging box indicator light

Wearing

1. The correct way to wear
L is the left ear, and R is the right ear. For a more comfortable audio experience, please try on each size of ear tips. Try wear the earphone correctly so that the earphones are closely and firmly seated in your ears.
2. Outdoor
The human body contains a lot of water and has strong interference to Bluetooth signals. Generally, the main earphone is set to receive the Bluetooth signal of the mobile phone, it is recommended that try to put the mobile phone in the pocket on the side of the main ear to effectively prevent the human body from blocking the signal and to improve the anti-interference ability during using



Instructions

1. Charging
a. Use the DCSV-1A Type-C to charge the case. The orange light is always on when charging, and the green light is always on when fully charged.
b. To charge the headset, please put the headset into the charging box and close the cover of the charging box, the headset will charge automatically.
2. Connect the Equipment
a. After opening the lid of the charging case, the left and right earphones are automatically turned on and paired.
b. Refresh the bluetooth device and search for T309, Then click to connect successfully.
3. Single Ear Connects the Equipment
a. The method of single earphone pairing is the same as the point 2. (Use the left ear alone, take out the left earphone and wait for about 10S to search for connection)
b. Reset the headset (reset the headset after the left and right ears are not paired or the Bluetooth cannot find the device)
a. When the Bluetooth is not connected, quickly press the MFB button 4 times on the left/right earphone, and there will be a "beep beep" prompt after clearing the connection record.

Function control

Power On	Long press the MFB key for 3S
Power Off	Headphones into warehouse
Pause/play music	Click on the MFB key
Previous song	Double-click the MFB button on the left ear
Next song	Double-click the MFB button on the right ear
To answering up an incoming call	Click on the MFB key
Reject incoming calls	Long press the MFB button for 2S
Turn on the voice mode	Triple click the MFB button on the left ear
Game mode	Triple-click the MFB button on the right ear

Product Parameter

Bluetooth version	5.3
Audio Formats	SBC、AAC
Working time	≥4H
Charging time (box)	<2H
Charging time (headphone)	<2H
Working distance	≥8m
Product size	52,2X22X48mm

Frequently Asked Questions

1. The earphone cannot be detected by the mobile
a. To determine whether the headset is turned on, restart the earphone and mobile phone, and repeat the above actions to search.
b. To make sure that the headset is not connected to other Bluetooth devices.
2. The left and right earphones cannot be paired
a. Put the earphone into the charging box and then take out to reconnection,
b. Reconnect the headset after resetting it.
3. There is disconnections or noises in the connection between the earphone and the mobile phone
a. There are obstacles or other electrical signal interferences between the device and the earphone, Please keep the earphone and the device free of obstacles, and try not to use it in a complex environment.
b. The effective working range of earphones and equipment is up to 8 meters, Generally, the situation without obstacles can achieve the best results, There will be noises and disconnections beyond the effective distance.
4. The headphone cannot be charged,
a. Please make sure that the headset is connected with the charging box,
b. To make sure whether there are dirt or water stains on the charging contact point, Please keep it clean,